

Фильтрующие устройства с капюшоном SEKUR escABEK-P3 15, SEKUR esCAPe

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eut@nt-rt.ru || сайт: <https://ekastu.nt-rt.ru>



Technical Data Sheet

SEKUR escABEK-P3 15

Order no.:	466 428	
Product designation:	Filtering Escape Device with Hood SEKUR escABEK-P3 15	
Applied standard:	DIN 58647-7-ABEK 15 additionally DIN EN 14387 ABEK P3	
Utilization:	Filtering Escape Devices SEKUR escABEK-P3 15 are determined for self-rescue from chemical danger areas. The scope of protection is determined by the product information, technical standards and valid application rules.	
Operation time:	approx. 15 min.	
Description:	The Filtering Escape Device is equipped with a heat resistant hood made of Teflon foil (PTFE). Furthermore, it is chemical resistant against the vast majority of materials. The Filtering escape device is provided with a mouthpiece and a nose clip, thereby it is achieving an ultimate tightness in contaminated environments. Due to the uniqueness of the mouthpiece, the device is ideal for all users, also for spectacle and beard wearers.	
Materials:	Mouthpiece Nose clip Fitting clamp Hood Filter case Sorbents Carrying and Storage Case Belt clip	EPDM (Ethylene-Propylene-Diene-Mixture) Plastic (ABS) Metal Teflon foil (PTFE) Polybutylene terephthalate (PBT) Impregnated active charcoal Plastic (ABS) Spring steel
Weight:	approx. 310 g (without plastic case) approx. 445 g (with plastic case)	
Inhalation resistance:	at 95 l/min, constant flow	max. 7,0 mbar (DIN 58647-7 / DIN EN 14387)
Exhalation resistance:	at 95 l/min, constant flow	max. 2,0 mbar (DIN 58647-7 / DIN EN 14387)
Marking:	Trade mark of manufacturer (LOGO) Product designation Applied standard Expiry of shelf-life (MM/YYYY) CE-Identification Notified body Instruction for use (Pictogram) Type identifying marking	
Handling:	Take the Filtering Escape Device from the plastic cabinet directly before use. Use the Filtering Escape Device in accordance with the information brochure.	
Storage conditions:	Ambient temperature. Protect against cold, heat and humidity. Consider conditions noted on the packaging.	
Warning reference:	Please consider the information brochure!	
User references:	EKASTU Safety GmbH guarantees the indicated achievement according to class and type. It is to be noted that the laboratory test values can considerably deviate from those, which are reached in practice. The user must read and understand all functional information. Use the Respiratory protective devices with this information brochure, the relevant valid statutory regulations and the safety requirements of the profession associations, particularly the regulations for use in accordance with DGUV Rule 112-190 resp. DIN EN 529 'Respiratory protective devices – recommendation for selection, use, care and maintenance – guidelines'	



Technical Data Sheet

SEKUR esCAPE

Order no.:	466 429	
Product designation:	Filtering Device with Hood for Escape SEKUR esCAPE	
Applied standard:	DIN EN 403 (DIN = German Institute for Standardization)	
Utilization:	Filtering Devices for Escape are determined for self-rescue from hazard area. The scope of protection is determined by the product information, technical standards and valid application rules.	
Operation time:	approx. 15 min.	
Description:	The Filtering escape device is equipped with a hood made from Polyimide foil, which is resistant to heat and flame. The remaining materials are also heat-resistant as well as hardly inflammable. The Filtering escape device is equipped with a mouthpiece and nose clip, therefore it reaches the ultimate tightness in contaminated area. On the basis of uniqueness mouthpiece assembly is the device for all possible users suitable, even for beard bearers and spectacle wearers.	
Materials:	Mouthpiece assembly Nose clip Hood Filter case Sorbents Chemical catalyst Particle filter Plastic Cabinet Sealing	EPDM (Ethylene-Propylene-Diene-Mixture) Polyamide Polyimide foil Plastic (ABS) Impregnated active charcoal Hopcalite Microfiberglass Plastic (ABS) Polyethylene (gummed)
Weight:	approx. 360 g (without Plastic Storage Case) approx. 520 g (with Plastic Storage Case)	
Inhalation resistance:	at 100 l/min, constant flow max. 8.0 mbar (EN 403)	
Exhalation resistance:	at 100 l/min, constant flow max. 3.0 mbar (EN 403)	
Marking:	Trade mark of manufacturer (LOGO) Product designation Applied standard Expiry of shelf-life (MM/YYYY) CE-Identification Notified body Instruction for use (Pictogram) Type identifying marking	
Handling:	Take the Filtering Device for Escape from the plastic cabinet directly before use. Use the Filtering Device for Escape in accordance with the information brochure.	
Storage conditions:	Ambient temperature. Protect against cold, heat and humidity. Consider conditions noted on the packaging.	
Warning reference:	Please consider the information brochure!	
User references:	EKASTU Safety GmbH guarantees the indicated achievement according to class and type. It is to be noted that the laboratory test values can considerably deviate from those, which are reached in practice. The user must read and understand all functional information. Use the Respiratory protective devices with this information brochure, the relevant valid statutory regulations and the safety requirements of the profession associations, particularly the regulations for use in accordance with DGUV Rule 112-190 resp. DIN EN 529 'Respiratory protective devices – recommendation for selection, use, care and maintenance – guidelines'.	

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eut@nt-rt.ru || сайт: <https://ekastu.nt-rt.ru>